XP Foot Valve Replacement

Tools needed: 1. 3MM allen key/wrench 2. Adjustable wrench 3. Slip Joint pliers/channel locks

Step 1. Locate the 2 position air valve at the bottom left leg of the compactor and pull the handle “UP”. This will turn off the air to the machine allowing you to remove the BAD valve without the hazard of losing parts or having to deal with the noise.

2. Unscrew the three #3 metric allen bolts that hold the valve on. 3. Push in and hold the orange ring down to pull the hose out.

XP Foot Valve Replacement

the large nut attached to the elbow on the valve is where the 2 parts disconnect.

If the valve was shipped with the barb attached this end will have to be removed prior to install.

Installation is just the reverse of this